

## Non Pasted Wall Mural Instruction

### How to Install Non-Pasted Wallpaper or Wall Mural with Precision

*Applying non-pasted wallpaper or wall murals can transform any room into a space of beauty and inspiration. This guide provides step-by-step instructions for applying non-pasted wallpapers, including handling overlaps with the double-cut technique for a professional finish.*

#### Preparing Your Space

*Ensure your wall is clean, dry, and smooth. Any imperfections can affect the final appearance of your wallpaper. If necessary, apply a primer for a more adhesive-friendly surface. Remember, your wallpaper panels are designed to overlap slightly and are numbered from right to left for easier application.*

### Applying Your Non-Pasted Wallpaper

**Non-pasted wallpapers require an external adhesive. Use any branded wallpaper paste for best results. Follow these steps for a seamless application:**

- 1. Start by mixing your wallpaper paste according to the manufacturer's instructions.*
- 2. Apply a generous layer of paste to the wall using a brush or roller. For the best adhesion, also apply paste to the back of the wallpaper.*
- 3. Place the first panel on the far right side of the wall, aligning it carefully at the top and sides. Smooth it out to remove any air bubbles.*
- 4. Continue with the next panel, remembering that each piece will slightly overlap the previous one. The panels are numbered from right to left to aid in this process.*

### Handling Overlaps with the Double-Cut Technique

**To achieve a flawless look where the panels overlap, use the double-cut technique:**

- 1. Overlap the new panel over the previous one, ensuring the patterns align perfectly.*
- 2. Use a straightedge and a sharp knife to cut through both layers of wallpaper along the middle of the overlap.*
- 3. Peel away the cut strips to reveal a perfect seam, then smooth down the edges to secure them in place.*

#### Finishing Touches

*After all panels are applied, go over the wallpaper with a soft cloth or a smoother to ensure full adhesion and to remove any remaining air bubbles. Trim any excess wallpaper at the top and bottom for a neat finish.*

## Caring for Your Wallpaper

*Allow your wallpaper to dry completely, avoiding any direct heat or sunlight. This will ensure the paste adheres properly, and your wallpaper remains beautiful for years to come.*

## Explore More

*Installing non-pasted wallpaper or wall murals can dramatically change the look and feel of any room. For more designs and installation tips, visit our Wall Murals and Wallpapers section.*

## Advanced Technique: Double-Cut for Perfect Overlaps

*For those looking to achieve an even more professional finish, particularly when working with overlapping wallpaper or mural panels, the double-cut technique is invaluable. This method ensures that your overlaps*

## Understanding the Double-Cut Technique

*The double-cut technique involves overlapping two sections of wallpaper or mural and cutting through both layers at once. This creates a perfect match at the seams, making them appear seamless.*

## Executing the Double-Cut

- 1. Apply the first panel and then overlay the second panel on top, ensuring a 2-inch overlap for proper pattern alignment.*
- 2. Use a straight edge and a sharp utility knife to cut through both layers of the wallpaper along the overlap.*
- 3. Gently remove the excess pieces from both layers, then smooth down the edges to ensure they adhere perfectly, leaving no visible seam.*

## Tips for a Successful Double-Cut

- Always use a sharp blade to ensure a clean cut without tearing the paper.*
- Be precise and gentle when removing the excess paper to avoid damaging the wallpaper.*
- Practice this technique on spare pieces before attempting it on your wall to ensure confidence and precision.*
- This advanced method will elevate your mural or wallpaper installation, ensuring a stunning, professional-grade finish. For more detailed instructions and to explore our wide range of Wall Murals, visit our website.*